

**MIGHTY BRIGHT®  
BATTERY SAFETY****KEEP THIS VERY IMPORTANT INFORMATION**

- **WARNING!** Mighty Bright products are not toys and are NOT FOR CHILDREN UNDER THIRTEEN. Please do not place within reach of young children.
- Do not look directly into the Light Emitting Diodes (LEDs) or Incandescent bulbs and do not shine them into the eyes of others. As with other high intensity light sources, eye damage may occur.
- Improper use of this or any battery-operated product may cause batteries to leak or explode, which may cause personal injury. Battery leaks can cause chemical burns.
- If batteries leak and come in contact with skin, eyes, inside of mouth or anywhere on the body:
  1. IMMEDIATELY flush the affected area with plenty of cold running water (not hot water).
  2. Contact your local doctor or local poison control center or hospital Emergency Room.  
In the United States call the 24-hour National Button Battery Ingestion Hotline -- 1-202-625-3333 -- that accepts collect calls from both U.S. and Canadian citizens. If injury appears serious, call "911."
  3. DO NOT ALLOW ANY METALLIC MATERIAL TO TOUCH THE INSIDE OF THE BATTERY COMPARTMENT OR ANY OF THE BATTERIES. Such contact may cause batteries to heat up and leak or explode, which may cause personal injury.

**ELECTRICAL POWER SOURCES**

- Mighty Bright products use either batteries or AC Adapters (on some models) for electrical power.
- Battery types may include one of the following:
  - four (4) AA 1.5V batteries
  - three (3) 1.5 V AAA batteries
  - two (2) CR2016 3V Lithium batteries
  - two (2) CR2032 3V Lithium batteries
  - three (3) G13A or V13GA or LR44
  - three (3) D batteries

**INSERTING / REPLACING BATTERIES**

- Open the battery door and insert the batteries so the positive end (+) and the negative end (-) align as illustrated in the battery compartment diagram.
- The negative end (-) is always aligned with any spring mechanism.
- Please be careful to follow the same alignment direction for each battery when using any button cell or AAA batteries.
- AA batteries for the Classic incandescent light and D batteries for the Floor Light & Magnifier have alternating alignment.
- AA and AAA alkaline batteries are recommended to provide maximum battery life.
- Do not mix battery brands. (All batteries used in the light must be the same brand.) For best results do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Use all alkaline, or all standard, or all rechargeable batteries.
- Do not attempt to recharge non-rechargeable batteries.
- Remove batteries when light output becomes weak or nonexistent.
- Please recycle all used batteries in compliance with local regulations.
- For LED lights that contain both white and red LEDs the red LEDs will be illuminated for a longer duration than the white LEDs as the battery power decreases. This is due to the lower amount of power required by the red LEDs.
- Remove batteries when the light is not in use for long periods to avoid damage that may occur from battery corrosion. It is also best to remove all batteries before using an AC Adapter.

## **AC ADAPTERS (SWITCHING POWER SUPPLY)**

- The AC Adapter (Switching Power Supply) is an optional accessory for most models and is included in some Deluxe models.
- Mighty Bright AC Adapters have these specifications:
  - LED, US / Japan – For use with LED lights requiring 3 AAA batteries or the MiniFlex LED light; Input 100 - 240V, 60 Hz, 2.5 W; Output 4V; DC Current 100mA Max
  - Incandescent, US - Use only with incandescent lights requiring 4 AA batteries; Input 120V, 60 Hz, 2.5 W; Output 4.8V; DC Current 100mA Max
  - LED, UK / Euro - For use with LED lights requiring 3 AAA batteries or the MiniFlex LED Light; Input 100 - 240V, 50-60 Hz, 0.1A; Output 4V; DC Current 100mA Max.
- Use only a Mighty Bright AC Adapter. Use of any other adapter type may cause personal injury and/or damage the light.
- LIGHT EMITTING DIODES (L.E.D.s)
- LEDs may last up to 100,000 hours and are not replaceable. DO NOT ATTEMPT TO REMOVE OR REPLACE THE LIGHT EMITTING DIODES. In the unlikely event your light fails, please contact Mighty Bright.

Mighty Bright - Gold Crest, LLC  
650 Ward Drive, Suite A  
Santa Barbara, CA 93111 USA  
800-922-3233 (U.S.A)  
805-683-9000